

Shimmering Velvet Earrings



Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Fancy Stones	4470	2 pcs	10mm	Light Colorado Topaz Shimmer F	246 971
Crystal Pearls	5810	2 pcs	10mm	Crystal Velvet Brown	001 951
Crystal Pearls	5810	2 pcs	5mm	Crystal Velvet Brown	001 951
Crystal Pearls	5810	2 pcs	3mm	Crystal Velvet Brown	001 951
Sew On	3230	2 pcs	12x7mm	Light Colorado Topaz Shimmer F	246 971

Supplies:

2 10mm link settings "Almost Instant Jewelry" by Fire Mountain Gems #H20-3040MT

4" 20 gauge Gold Artistic Wire

2 ear wires

2 1" head pin

Swarovski crystal two-part epoxy glue

Alcohol wipes

Instructions

- Step 1: Using the alcohol wipes clean each of the 10mm link settings. Using the two part epoxy, glue into each of the 10mm link settings the 4470 10mm light Colorado topaz shimmer cushion stones. Set aside to dry.
- Step 2: Cut the 20 gauge wire into four 1" pieces.
- Step 3: Using one piece of wire make a simple loop, slide on one 5810 10mm velvet brown pearl and make a simple loop. Repeat once more time and set aside.
- Step 4: Using one piece of wire make a simple loop, slide on one 5810 5mm velvet brown pearl and make a simple loop. Repeat once more time and set aside.
- Step 5: Using one head pin, slide on one 5810 3mm velvet brown pearl and make a simple loop. Repeat once more time and set aside.
- Step 6: To create earring: Starting with an ear wire attach to the 10mm pearl component made in Step 3, then attach to one cushion component made in Step 1, then attach one 5mm pearl component made in Step 4, then attach one 3230 12x7mm light Colorado topaz shimmer sew on, and finally one 3mm pearl component made in Step 3.
- Step 7: Repeat Step 6 to make second earring.