



LEVEL
EASY

Textured Cuff

TOOLS & SUPPLIES NEEDED

Texture Stamper Hammer
Steel Block
Bracelet Bending Bar
Bracelet Bending Pliers
Texture Stamp Pack, Series 3
Aluminum Bracelet Blanks, 1/4in & 3/8in

Instructions



STEP 1

Place texture stamp of your choice in the Texturizer Hammer



STEP 2

Stamp the bracelet blank repeatedly until the entire blank is textured



STEP 3

Use the Bracelet Bending Bar to bend the blank into a cuff shape. Place end of blank into bending bar face-up and hold securely. Bend the blank around the bar and repeat on other side.



STEP 4

Continue to round out the cuff with Bracelet Bending Pliers.